



East Coast Supercharging
562 Route 539
Cream Ridge, NJ 08514

ECS Torque Tube Tamer Instructions:



-Start by modifying your tunnel plate, measure about 4" from the back of the plate and cut straight across.



-Next mount the torque tamer lower plate to the last two tunnel plate bolt holes using the supplied 6mm bolts.

-Next using the supplied riv nut insert and install tool mark the last hole on each side and drill using a drill bit. Install the riv nut insert along with the final two rear 6mm bolts.



-Secure all six 6mm bolts and slide the tamer loop over the torque tube and secure using the supplied hex nuts. Use supplied shims to make sure the loop is just barely touching the torque tube, you do not want excessive tension pulling down on the loop/torque tube or that will transmit a lot of driveline vibrations to the chassis. The point of the Torque Tube Tamer is to prevent the torque tube from flexing upwards not meant to be used to secure the torque tube down.

